

Lake Lite - Boat House Solar Light Kit

Model: LL-GZB-LED-KIT




LAKE LITE
100 Industrial Dr.
Avilla, IN 46710

Phone: 260-918-2758
E-mail: sales@lakelite.com
Web: www.lakelite.com

Lake Lifter - Boat House Solar Light Kit


Model: LL-GZB-LED-KIT

IMPORTANT !



The battery should be mounted in the most upright position. If you mount the control box upside down remove the battery and flip it around so the battery will be up right after installing the control box.

CONNECT FUSE !



NOTE:

The fuse is shipped disconnected. Insert fuse and close control box cabinet before operation.

Use the provided wiring to connect the components as shown. You may purchase additional wiring lengths to extend or shorten the distances between each component: Visit: www.lakelite.com

Connection Diagram

