
## **Control Box Overview**

LAKE LIFTER: 100 Industrial Drive, Avilla IN 46710

Ph: 260-918-2758

Email: sales@lakelifter.com





## **Battery & Regulator Connections**

Ph: 260-918-2758 Email: sales@lakelifter.com



DC POWERED BOAT LIFT MOTORS



LAKE LIFTER: 100 Industrial Drive, Avilla IN 46710

Place 12v-35A (AGM) style battery into box.



Secure the solar charge regulator anywhere inside the box




Connect the power cables for both motor & solar charge regulator to the battery terminals



Feed the motor wires through the louver vent and connect them to the M1 and M2 studs



Connect the motor wires to the contactor studs labeled M1 & M2:





Mount the aluminum bracket to the back of the fiberglass box


## **Battery & Solar Mounted on Lift**


LAKE \( \shape \) LIFTER


LAKE LIFTER: 100 Industrial Drive, Avilla IN 46710 Ph: 260-918-2758 Email: sales@lakelifter.com











After mounting the winch to the lift, place the sticker over the exposed holes.







Example of finished installation on vertical lift

Example of finished installation on cantilever lift