


LAKE LIFTER: 100 Industrial Drive, Avilla IN 46710 Ph: 260-918-2758 Email: sales@lakelifter.com



Battery & Regulator Connections

LAKE LIFTER: 100 Industrial Drive, Avilla IN 46710

Ph: 260-918-2758 Email: s

58 Email: sales@lakelifter.com





Place 12v-35A (AGM) style battery into box.



Secure the solar charge regulator anywhere inside the box



Feed the motor wires through the louver vent and connect them to the M1 and M2 studs



Connect the motor wires to the contactor studs labeled M1 & M2:



Connect the power cables for both motor & solar charge regulator to the battery terminals



Mount the z-bracket box feet to the box. IMPORTANT add middle support to prevent box sag from battery weight

Battery Solar Box Mounted on Dock




LAKE LIFTER: 100 Industrial Drive, Avilla IN 46710


N 46710 Ph: 260-918-2758

58 Email: sales@lakelifter.com



The Winch box is universal and can be mounted on either side of the lift.





After mounting the winch to the lift, place the sticker over the exposed holes.



IMPORTANT – MOUNTING FEET REQUIRED! LAKE CLIFTER

- 1. Install all 4 box feet as shown: These will elevate the box to allow for any drainage.
- 2. Install two stick on supports as shown. (prevents box sag over time due to battery weight)

